


SERVICE MANUAL



DIGITAL COMPACT DISC PLAYER WITH RAD-Z1 WIRELESS REMOTE CONTROL

AD-Z1

(EUROPE)



137 348 40 (EUROPE)
137 348 41 (SWISS)

SPECIFICATIONS

System Compact disc digital audio system
Remote Control (RAD-Z1) 30-function
wireless remote control

AUDIO CHARACTERISTICS

Frequency Response 2 Hz ~ 20 kHz ± 0.5 dB
Total Harmonic Distortion Less than 0.0025% (1 kHz)
S/N Ratio (IHF, A-Network) More than 110 dB
Dynamic Range More than 98 dB
Wow and Flutter Below measurable limits
Channel Separation More than 100 dB (1 kHz)
Output Voltage max. 2 Vrms
Output Level and Impedance

Headphones 0 ~ 500 mV/8 Ω
Digital Output System Digital audio interface format
Optical Output -15 dBm ~ -21 dBm
Coaxial Output 500 mVp-p/75 Ω $\pm 20\%$

FUNCTIONS

Program Functions 20 selections
Scanning 2 speed fast-forward/back with sound,
2 speed search in PAUSE mode

Intro-Scan 10 sec. or 1 ~ 99 sec. programmable
with the remote control
Random Disc Play With RANDOM PLAY button
on the remote control
Repeat One track, All tracks,
All programmed tracks,
or A through B with the remote control
Disc Loading Motor driven horizontal loading

DIGITAL SIGNAL PROCESSING

Optical Pickup 3-beam laser
Error Correction CIRC
Sampling Frequency 44.1 kHz
D/A Conversion 2 D/A converters
18-bit linear
Filters 8-times oversampling digital filter,
linear phase analog filter

GENERAL

Power Requirements AC: 220V
(50 Hz) 30 Watts
Dimensions (WxHxD) 480 x 130 x 325mm
Weight (approx.) 8.4 kg


— Specifications and design are subject to change without notice. —

REFERENCE No. WM-570340


CD PLAYER DISASSEMBLY PROCEDURES

REMOVING THE DISC TRAY

1. Push the POWER button to switch the power on and push the OPEN/CLOSE button to open the Disc Tray.
2. Push the POWER button to switch the power off while the Disc Tray is open.




3. Now remove the Disc Tray from the cabinet while pressing the tab in the direction of the arrow in the diagram below.




REMOVING THE MECHANISM

1. Take out the four screws (1 ~ 4 in the diagram below) with which the mechanism is mounted in place and remove the mechanism.




2. The mechanism should be removed with the lead wires still attached, and then placed on a wooden or plastic sheet as shown below to adjust the diffraction grating.



NOTE FOR ASSEMBLING DISC TRAY

1. Place the Disc Tray lever as illustrated and assemble the disc tray.



SAFETY CERTIFICATION


CAUTION - INVISIBLE LASER RADIATION WHEN OPEN AND
INTERLOCKS DEFEATED AVOID EXPOSURE TO BEAM.
VORSICHT: UNSICHTBARE LASERSTRAHLUNG TRITT AUS
WENN DECKEL GEÖFFNET UND WENN
SICHERHEITSVORRICHTUNGEN ÜBERBRÜCKT WERDEN.
NICHT DEM STRAHL AUSSETZEN!
VARNING - OSYNLIG LASERSTRÅLNING NÄR DENNA DEL
ÄR ÖPPNAD OCH SPARR AR URKOPPLAD
STRÅLEN ÄR FARLIG
ADVARSEL - OSYNLIG LASERSTRÅLING VED ÅBNING, NÅR
SÆKREDELSISFORRETNINGER ER UDE AF FUNKTION.
UNDGÅ UDSETTELSE FOR STRÅLING

Laser Diode Properties

Material: Ga-Al-As

Wavelength: 755 – 815 nm (25°C)

Laser Output: Continuous Wave max. 0.5 mW




CLASS 1 LASER PRODUCT

CAUTION – USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

THE COMPACT DISC PLAYER SHOULD NOT BE ADJUSTED OR REPAIRED BY ANYONE EXCEPT QUALIFIED SERVICE PERSONNEL.

CD MAIN P.C.BOARD ALIGNMENT POINTS (TOP VIEW)



CD PLAYER ADJUSTMENT PROCEDURES

BEFORE CHECKING OR ADJUSTING CD PLAYER

1. Procedures for all adjustments for the CD player from start to finish are described below.
2. If no problems are found after each item is checked when the pick-up is replaced, there is no need to adjust all items again.

SETTING OF INITIAL POSITION OF VOLUME

1. Set the variable resistors to the initial positions listed below:

P101 (E/F BALANCE)		Mechanical Center
P102 (TRACKING GAIN)		Mechanical Center
P103 (TRACKING OFFSET)		Mechanical Center
P104 (KICK GAIN)		Mechanical Center
P105 (FOCUS OFFSET)		Mechanical Center
P106 (FOCUS GAIN)		Mechanical Center
P107 (LINEAR MOTOR OFFSET)	..	Mechanical Center

FREE RUN FREQUENCY ADJUSTMENT


1. Connect the frequency counter to VCO test terminal **TP8 PCK** test pin and to **GND**. (Use a 10:1 probe.)
2. Short the test point **TP6 OSC ON** pin to **GND**.
3. Push the POWER button to switch the power on and push the STOP button.
4. Adjust the OSC coil T102 using a plastic screwdriver until the frequency counter indicator reads 4.3218MHz ± 10 kHz.

LINEAR MOTOR OFFSET ADJUSTMENT

1. Push the POWER button to switch the power on and push the STOP button.
2. Connect a DC Voltmeter to the test terminal **TP7 LINEAR MOTOR** pin, to **GND**.
3. In this condition check that the DC Voltmeter indicator is in the range $0V \pm 100mV$, and adjust P107 if it is not.

E/F BALANCE ADJUSTMENT

1. Place the test disc (Modern Wave II) on the Disc Tray, and play the fourth item on the disc. Short the test point **TP3 TEST** pin to **GND**, and test terminal **TP5 TROFF** pin to **GND** to turn tracking servo OFF.
2. Connect a DC Voltmeter and an oscilloscope via the low-pass filter like that shown in the illustration below to the test terminal **TP5 TE** (tracking error) pin.



Measurement circuit

3. Adjust P101 so that the DC Voltmeter reading is $0V \pm 50mV$ (oscilloscope waveform is symmetric to + and - about the zero level).

FOCUS GAIN ADJUSTMENT

1. Apply P106 to the position of Mechanical center position, and place the test disc (Modern Wave II) on the Disc Tray.
2. Connect the measurement tool described in the last section to connector (CN5).
3. Connect the Pick-up Connector Plug to the measurement circuit.
4. Push the POWER button to switch the power on and PLAY the first item on the test disc. Now apply a signal of 900Hz and 0.3Vp-p from the signal generator to the measurement circuit.
5. Set the oscilloscope to X-Y operation, and while observing the lissajous waveform adjust P106 to the point where the phase difference is 90° as shown in Fig. 1 below.




Fig.1

TRACKING GAIN ADJUSTMENT

1. Apply P102 to the position of Mechanical center position, and place the test disc (Modern Wave II) on the Disc Tray.
2. Connect the measurement tool described in the last section to the connector (CN5).
3. Connect the Pick-up Connector Plug to the measurement circuit.
4. Push the POWER button to switch the power on and PLAY the first item on the test disc. Now apply a signal of 1400Hz and 0.3Vp-p from the signal generator to the measurement circuit.
5. Set the oscilloscope to X-Y operation, and while observing the lissajous waveform adjust P102 to the point where the phase difference is 90° as shown in Fig. 1 above.

NOTE:


If these two adjustments are performed, the TRACKING OFFSET must also be adjusted.

CD PLAYER ADJUSTMENT PROCEDURES (Continued)

ADJUSTMENT OF FOCUS/TRACKING GAIN

The measurement circuit diagrammed below must be used in order to adjust focus gain and tracking gain correctly.

1. Use IC TA7256P or an equivalent product.
2. Short the interval between **IN** and **SG**, apply 1kHz, 1Vp-p from **SG**, and adjust variable resistor 2k Ω -B so that the **OUT** output is minimum.



Measurement circuit

FOCUS OFFSET ADJUSTMENT

1. Push the POWER button to switch the power on and push the OPEN/CLOSE button to open the Disc Tray and remove the disc.
2. Push the OPEN/CLOSE button to close the Disc Tray and push the STOP button.
3. Connect a DC Voltmeter to the test terminal **TP7 FC** (focus coil) pin and short the test terminal **TP8 FOFF** pin to **GND**.
4. In this condition check that the DC Voltmeter indicator is in the range $-0.5V \pm 50mV$, and adjust P105 if it is not.

TRACKING OFFSET ADJUSTMENT


1. Push the POWER button to switch the power on and push the STOP button.
2. Connect a DC Voltmeter to the test terminal **TP7 TC** (tracking coil) pin and short the test point **TP8 TOFF** pin to **GND**.
3. In this condition check that the DC Voltmeter indicator is in the range $100mV \pm 50mV$, and adjust P103 if it is not.

NOTE:

Perform this adjustment once again after adjusting the E/F BALANCE and TRACKING GAIN signals.

KICK GAIN ADJUSTMENT

1. Place the test disc (Modern Wave II) on the Disc Tray.
2. Set the oscilloscope to NORMAL TRIG., set the EXT. TRIG. pin to external trigger, and input the trigger from test point **TP8 THLD** pin to the oscilloscope.
3. Next connect test point **TP6 HF** pin to Channel 1 of the oscilloscope, and connect test terminal **TP5 TE** pin to Channel 2.
4. Push the POWER button to switch the power on and PLAY the first item on the test disc, and then push the PAUSE button. Now observe the waveforms for **HF** and **TE** with triggers applied from test point **TP8 THLD** pin. At this point, adjust P104 so that a kick pulse waveform of about 1 to 1.3 tracks as shown in Fig. 2 below is obtained.



Adjustment must be performed so curve section in Fig.2 appears.

Fig.2

CD PLAYER ADJUSTMENT PROCEDURES (Continued)

D/A CONVERTER DISTORTION ADJUSTMENT

1. Change the Output Selector Switch to ANALOG position.
2. Connect the Harmonic Distortion Meter to the LINE OUT jack through the Amplifier (60dB) and Low Pass Filter (20kHz).
3. Place the test disc YEDS7/YEDS18 (SONY) on the Disc Tray, and play the 1kHz (-60dB).
4. Adjust the AUDIO P.C.Board VR301 (Left channel) and VR302 (Right channel) so that distortion is at a minimum level (less than 1.6%).
5. Disconnect the Amplifier (60dB) and play the 1kHz (0dB).
6. In this condition check that the Distortion meter indicator is less than 0.003%.


CONFIRMING HF LEVEL

1. PLAY the fourth item on the test disc (Modern Wave II).
2. Connect an oscilloscope to the test point **TP6 HF** pin, and check that its HF level is in the range $2.6 \pm 0.5V(p-p)$.
3. If the results of the above procedure are not satisfactory, the Pick-up is damaged.


ADJUSTMENT OF TURNTABLE HEIGHT

This adjustment must be performed when the Spindle Motor is replaced.

1. The turntable should be mounted so that its upper surface is $13.75mm \pm 0.1mm$ above the surface of the chassis.




2. Place the test disc (Modern Wave II) on the turntable.
3. Connect a DC Voltmeter and an oscilloscope via the low-pass filter shown below to test terminal **TP7 FC** (focus coil) pin.




Measurement circuit

4. Push the POWER button to switch the power on and PLAY the First and Last Track No. on the disc.
5. If the DC Voltmeter reading is not in the ranges $0V \pm 0.2V$ for inner tracks and $0V \pm 0.35V$ for outer tracks, then the turntable height must be readjusted. Raise the turntable higher if the DC Voltmeter indicator is on the plus (+) side, and lower it if it is on the minus (-) side.
(With this circuit 1V represents movement of approximately 0.55mm ~ 0.65mm.)

CABINET EXPLODED VIEW (1)




CABINET EXPLODED VIEW (2)



CABINET PARTS LIST

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
PACKAGE				or	620 053 2129	Bushing (Power Cord)	1
	620 000 0024	Bag Polyethylene	1	41	620 189 1195	Knob Volume (Level Volume)	1
	620 201 8935	Outer Carton	1	42	△ 620 006 6679	Capacitor 0.01MF400V (C1)	1
	620 196 4844	Sheet,Poly	1	43	△ 620 016 7598	Power Switch	1
	620 195 3787	Pad,Bottom	1	44	△ 620 023 7550	Power Cord	1
	620 195 3794	Pad,Top	1	45	620 050 4409	Mount P.C.B	2
	620 152 7452	Serial No. Sheet	2	46	620 201 7099	Cap,Wood	4
ACCESSORIES				47	620 201 9949	Spacer	4
	620 202 7838	Assy,Poly Cover	1	48	620 203 7073	Cushion	4
	620 202 7845	Instruction Manual	1	50	620 202 0129	Assy,PCB,Main	1
	620 196 9757	Cord	1	51	620 197 2016	Assy,PCB,Control	1
	620 196 2826	Opto Connector,DIG I/O	1	52	620 197 2023	Assy,PCB,LED	1
	620 152 2624	Certificate Card	1	53	620 202 0136	Assy,PCB,Filter	1
	620 152 7452	Serial No. Sheet	1	54	620 197 2276	Assy,PCB,Audio	1
	620 057 8783	Bag Fan	1	55	620 197 2313	Assy,PCB,Audio Sub	1
	620 197 0562	Remocon,RAD-Z1 (Remote Control)	1	56	620 197 2498	Assy,PCB,Headphone	1
	620 198 9786	Label	1	70	411 020 5508	SCR S-TPG BRZ 2.6X6	13
CABINET				71	411 020 6802	SCR S-TPG BRZ 3X18	4
	620 018 1495	Connector 3P Assy (CN9W)	1	72	411 020 7700	SCR S-TPG BRZ 3X6	26
	620 018 1501	Connector 3P Assy (CN10W)	1	73	411 099 9704	SCR S-TPG BRZ 3X6	10
	620 018 1976	Connector 2P Assy (CN6W)	1	74	411 099 9803	SCR S-TPG BRZ 3X8	8
	620 018 2157	Connector 1P Assy (CNTP1)	1	75	411 021 0809	SCR S-TPG BIN 2X6	8
	620 022 3454	Terminal Lug	1	76	411 021 2704	SCR S-TPG BIN 2.6X6	1
	403 072 2703	CERAMIC 0.022U Z 50V (C2)	1	77	411 021 5903	SCR S-TPG BIN 3X6	3
	620 197 2696	Assy,Connector-S,2P (Load Motor)	1	78	411 021 6603	SCR S-TPG BIN 3X8	10
	620 197 2702	Assy,Connector-S,4P (Spindle Motor)	1	79	411 021 9109	SCR S-TPG BIN 4X6	2
	620 201 8997	Cover,Safety	1	80	411 003 8908	SCR PAN + SW 3X6	2
	620 061 2340	Notes (Laser)	1	81	411 004 5906	NUT HEX 5	4
	620 061 2401	Notes (Laser)	1	82	412 033 7602	SPECIAL SCREW	4
	620 061 2418	Notes (Laser)	1	83	411 082 9605	SCR WOOD FLT 3.1X16	4
	620 125 8103	Lug	2	84	412 033 7909	SPECIAL WASHER	4
	620 125 8110	Lug	1	85	412 033 7404	SPECIAL SCREW	4
	620 125 8424	Wire Band	11	86	620 122 6423	Screw, PAN + M2.6X5.0	2
	620 152 7452	Serial No. Sheet	1	88	412 034 8509	SPECIAL SCREW	3
1	620 196 4233	Assy,Cabinet,Front	1	NOTES:			
2	620 196 4240	Assy,Panel,Front	1	1.	Parts order must contain Model Number, Part Number and Description.		
3	620 201 8508	Assy,Foot (Europe)	4	2.	Ordering quantity of screws and resistors must be multiple of 10 pcs.		
3	620 195 9413	Assy,Foot (Swiss)	4	PRODUCT SAFETY NOTICE Each precaution in this manual should be followed during servicing. Components identified with the IEC symbol △ in the parts list and the schematic diagram designate components in which safety can be of special significance. When replacing a component identified with △, use only the replacement parts designated, or parts with the same ratings of resistance, wattage or voltage that are designated in the parts list in this manual. Leakage-current or resistance measurements must be made to determine that exposed parts are acceptably insulated from the supply circuit before returning the product to the customer.			
4	620 195 3886	Cover,Top	1				
5	620 196 1263	Plate,Bottom	1				
6	620 201 8881	Panel,Rear	1				
7	620 201 7754	Panel,Side,Wood,Left (Europe)	1				
7	620 195 3732	Panel,Side,Wood,Left (Swiss)	1				
8	620 201 7761	Panel,Side,Wood,Right (Europe)	1				
8	620 195 3749	Panel,Side,Wood,Right (Swiss)	1				
9	620 196 0549	Panel,Tray	1				
10	620 196 0655	Button,Small	1				
11	620 195 5514	Button,Power	1				
12	620 196 0662	Button,Number 1-5	1				
13	620 196 0679	Button,Number 6-0	1				
14	620 196 0556	Foot,Mecha-1	2				
15	620 196 0563	Foot,Mecha-2	2				
16	620 195 1943	Handle	2				
17	620 196 1225	Chassis,Main	1				
18	620 196 1232	Chassis,Center	1				
19	620 196 1218	Chassis,Front	1				
20	620 196 0785	Bracket-E,Power	1				
21	620 196 0792	Bracket-E	1				
22	620 196 1201	Bracket-E,Power Switch	1				
23	620 196 1270	Bracket-E,PCB Shield	1				
24	620 195 3756	Cap,Lid	2				
25	620 195 3800	Spacer	4				
26	620 201 7105	Spacer,Wood	4				
27	620 199 5077	Cushion,Button-1	1				
28	620 199 5084	Cushion,Button-2	1				
29	620 197 5192	Pad,Damper	1				
30	620 196 4226	Fixer,Rivet	1				
31	620 196 2666	Adhesive Sheet,Tray	1				
32	620 197 5208	Adhesive Sheet,Foot-1	2				
33	620 197 5215	Adhesive Sheet,Foot-2	2				
34	620 198 6570	Sheet,Volume	1				
35	620 198 6600	Sheet,Disc Set	1				
36	620 198 6655	Sheet	1				
37	620 197 5758	Felt,Cushion-1	1				
38	620 197 5765	Felt,Cushion-2	3				
39	△ 620 201 8539	Power Trans,SEV,25VA	1				
40	620 053 2136	Bushing (Power Cord)	1				

MECHANISM EXPLODED VIEW



MECHANISM PARTS LIST

Ref. No.	Part No.	Description	Q'ty
MECHANISM			
	620 125 8424	Wire Band	3
	620 125 8424	Wire Band	2
1	620 062 6200	Pick-up Assy 88 BS	1
2	620 183 4871	Holder Bobbin Assy	1
3	620 183 4888	Bobbin Assy	1
4	620 183 5144	Spindle Motor Assy [M101]	1
5	620 195 2018	Assy,Bracket-E,Sensor	1
6	620 051 4316	Screw 3X10	2
7	620 195 2001	Assy,Chassis	1
8	620 121 6448	Yoke Center	2
9	620 183 4895	Yoke Side Assy	2
10	620 122 6324	Screw Washer + 2.6X6.0	2
11	620 123 0116	Set Screw V-Cone 2X4	1
12	620 124 3321	Cushion	1
13	620 126 4111	Turntable	1
14	620 133 4104	Shaft Pick-up	2
15	620 015 3843	Leaf Switch (Open/Close) [SW101]	1
16	620 030 4108	Motor (Loading Motor) [M102]	1
17	620 083 2878	Gear Rack Assy	1
18	620 196 0594	Table,Loading	1
19	620 184 9592	Table CD Assy	1
20	620 117 1280	Chassis (Load)	1
21	620 119 2223	Holder Disc	1
22	620 196 4479	Yoke,Magnet	1
23	620 122 9738	Screw Bind HD. + M3.0X8	2
24	620 124 3437	Cushion Rubber	2
25	620 124 3444	Cushion Rubber	2
26	620 124 3628	Cushion Flap	1
27	620 184 9905	Pad Disc (Felt)	4
28	620 125 0145	Cushion Table Load	1
29	620 125 1005	Washer	1
30	620 127 9597	Gear Pulley	1
31	620 127 9603	Gear Pinion	1
32	620 128 6816	Belt	1
33	620 129 5993	Flap Disc Cramp	1
34	620 131 9835	Lever Table Load	1
35	620 133 4241	Shaft Damper	1
36	620 136 0769	Guide Table Load	2
37	620 138 0088	Spring Damper	1
38	620 139 2043	Spring Flap	1
39	620 139 4672	Spring Table CD	4
40	620 184 3026	Magnet Disc Clamp	1
41	620 192 6606	Pad Disc Hold	1
42	620 192 6613	Pad Damper	1
43	620 195 7709	Assy,PCB,Spindle,Motor	1
44	620 191 3507	Support Spindle	1
45	620 125 0923	Thrust Washer	1
46	620 184 2708	Guide Center	1
47	620 187 2859	Spring Guide Center	1
51	411 020 8004	SCR S-TPG BRZ 3X8	2
52	411 099 9704	SCR S-TPG BRZ 3X6	1
53	411 099 9803	SCR S-TPG BRZ 3X8	1
54	411 021 0601	SCR S-TPG BIN 2X5	2
55	411 030 6403	SCR BIN 2X5	2
56	411 099 9407	SCR S-TPG BRZ 2.6X8	2
57	411 021 0304	SCR S-TPG BIN 2X4	1
58	411 021 0908	SCR S-TPG BIN 2X6	1
59	411 031 0905	SCR BIN 2.6X4	2
60	412 026 0108	SPECIAL SCREW	1
61	412 032 8105	SPECIAL SCREW	4
62	411 015 8903	RING E 2	1
63	620 051 4316	Screw 3X10	1

NOTES:

1. Parts order must contain Model Number, Part Number and Description.
2. Ordering quantity of screws and resistors must be multiple of 10 pcs.

P.C.BOARD PARTS LIST

P.C.BOARD PARTS LIST (Continued)

Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty
SY,PCB,MAIN				Q104	405 035 8005	TR UN411-D	1	C135	403 067 7805	MT-COMPO	0.47U J 50V	R104	401 025 7805	CARBON	2.2K JA 1/6W
	620 202 0129	Assy,PCB,Main	1	Q105	405 035 8104	TR UN421-D	1	C136	403 026 8201	CERAMIC	470P K 50V	R105	401 025 8703	CARBON	220K JA 1/6W
	620 016 8434	Slide Switch 2P2T (Out Put Selector)	1	Q106	405 004 4601	TR 2SA608-F-SPA-AC	1	C137	403 067 8406	MT-COMPO	0.082U J 50V	R106	401 026 0607	CARBON	270 JA 1/6W
	620 017 2721	Fuse Clip	8	Q107	405 018 2600	TR 2SC3400-AC	1	C138	403 067 5603	MT-COMPO	0.1U J 50V	R107	401 026 7408	CARBON	39K JA 1/6W
	423 004 3301	FUSE 250V T0.8A	4	Q108	405 019 2807	TR 2SC536-F-SPA-AC	1	C139	403 026 8201	CERAMIC	470P K 50V	R108	401 024 9701	CARBON	12K JA 1/6W
	411 020 7700	SCR S-TPG BRZ 3X6	2	Q109	405 018 2600	TR 2SC3400-AC	1	C140	403 067 5603	MT-COMPO	0.1U J 50V	R109	401 024 9701	CARBON	12K JA 1/6W
	411 002 9005	SCR PAN 3X8	1	Q110	405 018 2600	TR 2SC3400-AC	1	C141	403 038 2402	ELECT	100U M 6.3V	R110	401 026 7408	CARBON	39K JA 1/6W
	620 202 0082	Jack,RCA,2P,Gold	1	Q111	405 003 7702	TR 2SA1346-AC	1	C142	403 045 9104	ELECT	220U M 25V	R111	401 026 1307	CARBON	27K JA 1/6W
	620 199 4742	Jack,RCA,1P,Gold	1	Q112	405 003 7702	TR 2SA1346-AC	1	C143	403 045 9104	ELECT	220U M 25V	R112	401 024 7707	CARBON	100K JA 1/6W
	620 196 1607	Converter,E/Q,Totx-174	1	Q113	405 018 2600	TR 2SC3400-AC	1	C144	403 026 9406	CERAMIC	5P C 50V	R113	401 026 4605	CARBON	33K JA 1/6W
	620 053 9036	Plate Heat Sink	1	Q114	405 018 2600	TR 2SC3400-AC	1	C145	403 067 5603	MT-COMPO	0.1U J 50V	R114	401 027 2600	CARBON	5.6K JA 1/6W
	620 053 9258	Plate Heat Sink	2	Q115	405 018 2600	TR 2SC3400-AC	1	C146	403 050 1308	ELECT	2.2U M 50V	R115	401 027 0507	CARBON	470K JA 1/6W
	620 197 2726	Assy,Connector-S,6P	1	Q116	405 018 2600	TR 2SC3400-AC	1	C147	403 038 7209	ELECT	220U M 6.3V	R116	401 027 2303	CARBON	580 JA 1/6W
	620 197 2733	Assy,Connector-S,7P	1	D101	407 000 3503	VARACTOR DI SVC211SP	1	C148	403 067 7805	MT-COMPO	0.47U J 50V	R117	401 024 7707	CARBON	100K JA 1/6W
	620 197 2757	Assy,Connector-S,2P,3P	1	D102	407 008 0405	DIODE GMB01-BT	1	C149	403 057 0106	POLYESTER	0.01U J 50V	R118	401 024 7707	CARBON	100K JA 1/6W
	620 021 5854	Plug 6P (Power Trans)	1	D103	407 008 0405	DIODE GMB01-BT	1	C150	403 067 5603	MT-COMPO	0.1U J 50V	R119	401 026 9907	CARBON	4.7K JA 1/6W
	620 021 5923	Plug 3P (Power Trans)	1	D104	407 008 0405	DIODE GMB01-BT	1	C151	403 086 2706	NP-ELECT	1U M 50V	R120	401 026 4308	CARBON	3.3K JA 1/6W
	620 021 8313	Plug 3P (Headphone P.C.B.)	1	D105	407 008 0405	DIODE GMB01-BT	1	C152	403 067 5603	MT-COMPO	0.1U J 50V	R121	401 025 7409	CARBON	220 JA 1/6W
	620 021 8337	Plug 6P (PU Sensor)	1	D106	407 005 3805	DIODE DS442-BT	1	C153	403 057 7204	POLYESTER	0.012U J 50V	R122	401 025 8208	CARBON	22K JA 1/6W
	620 021 8610	Plug 6P (PU ACT)	1	D107	407 008 0405	DIODE GMB01-BT	1	C154	403 057 7204	POLYESTER	0.012U J 50V	R123	401 025 8208	CARBON	22K JA 1/6W
	620 021 7620	Plug 2P (Linear Motor)	1	D108	407 005 3805	DIODE DS442-BT	1	C155	403 056 7304	POLYESTER	1000P J 50V	R124	401 025 8208	CARBON	22K JA 1/6W
	620 021 1970	Plug 2P (Loading Motor)	1	D109	407 005 3805	DIODE DS442-BT	1	C156	403 067 6709	MT-COMPO	0.22U J 50V	R125	401 025 8208	CARBON	22K JA 1/6W
	620 021 8597	Plug 4P (Spindle Motor)	1	D110	407 005 3805	DIODE DS442-BT	1	C157	403 056 7304	POLYESTER	1000P J 50V	R126	401 012 7009	CARBON	10K JA 1/4W
	620 021 8313	Plug 3P (Linear Sensor)	1	D111	407 008 0405	DIODE GMB01-BT	1	C158	403 067 5603	MT-COMPO	0.1U J 50V	R127	401 012 8105	CARBON	100K JA 1/4W
	620 021 7811	Plug 3P (Open/Close Switch)	1	D112	407 008 0405	DIODE GMB01-BT	1	C159	403 038 2402	ELECT	100U M 6.3V	R128	401 012 8105	CARBON	100K JA 1/4W
	620 021 8597	Plug 4P (Headphone Audio)	1	D113	407 008 0405	DIODE GMB01-BT	1	C160	403 038 2402	ELECT	100U M 6.3V	R129	401 016 3809	CARBON	2.2K JA 1/4W
	620 021 8344	Plug 10P (Main Control)	1	D114	407 008 0405	DIODE GMB01-BT	1	C161	403 067 5603	MT-COMPO	0.1U J 50V	R130	401 014 5201	CARBON	15K JA 1/4W
	620 021 8351	Plug 11P (Main Control)	1	D115	407 008 0405	DIODE GMB01-BT	1	C162	403 067 5603	MT-COMPO	0.1U J 50V	R131	401 012 5708	CARBON	1K JA 1/4W
	620 021 9976	Plug 8P (Main Control)	1	D116	407 008 0405	DIODE GMB01-BT	1	C163	403 067 7805	MT-COMPO	0.47U J 50V	R132	401 027 2600	CARBON	5.6K JA 1/6W
	620 021 8337	Plug 6P (Main Control)	1	D117	407 008 0405	DIODE GMB01-BT	1	C164	403 057 0106	POLYESTER	0.01U J 50V	R133	401 025 7805	CARBON	2.2K JA 1/6W
	620 021 9589	Inductor 10UH K	1	D118	407 008 0405	DIODE GMB01-BT	1	C165	403 067 5603	MT-COMPO	0.1U J 50V	R134	401 025 7805	CARBON	2.2K JA 1/6W
	620 202 0112	Inductor 2.2UH K	1	D119	407 008 0405	DIODE GMB01-BT	1	C166	403 004 0500	CERAMIC	0.047U K 25V	R135	401 025 7805	CARBON	2.2K JA 1/6W
	620 197 9589	Inductor 10UH K	1	D120	407 008 0405	DIODE GMB01-BT	1	C167	403 038 2402	ELECT	100U M 6.3V	R136	401 026 9907	CARBON	4.7K JA 1/6W
	620 197 9589	Inductor 10UH K	1	D121	407 070 4608	ZENER DIODE GZS30Y-BT	1	C168	403 067 5702	MT-COMPO	1U J 50V	R137	401 012 7009	CARBON	10K JA 1/4W
	620 006 2343	Potentiometer 100KB (E/F Balance)	1	D122	407 051 6706	ZENER DIODE GZS5.1Y-BT	1	C169	403 059 5604	POLYESTER	0.022U J 50V	R138	401 024 7400	CARBON	10K JA 1/6W
	620 006 1933	Potentiometer 100KB (Tracking Gain)	1	D123	407 005 8602	DIODE ERA15-02	1	C170	403 004 0500	CERAMIC	0.047U K 25V	R139	401 024 7400	CARBON	10K JA 1/6W
	620 006 1957	Potentiometer 20KB (Tracking Offset)	1	D124	407 005 8602	DIODE ERA15-02	1	C171	403 004 0500	CERAMIC	0.047U K 25V	R140	401 025 8208	CARBON	22K JA 1/6W
	620 006 1933	Potentiometer 100KB (Kick Gain)	1	D125	407 005 8602	DIODE ERA15-02	1	C172	403 004 0500	CERAMIC	0.047U K 25V	R141	401 025 4606	CARBON	16K JA 1/6W
	620 006 1957	Potentiometer 20KB (Focus Offset)	1	D126	407 005 8602	DIODE ERA15-02	1	C173	403 044 0300	ELECT	47U M 16V	R142	401 024 6700	CARBON	100 JA 1/6W
	620 006 1940	Potentiometer 10KB (Focus Gain)	1	D127	407 005 8602	DIODE ERA15-02	1	C174	403 063 5102	POLYESTER	8200P J 50V	R143	401 026 4605	CARBON	33K JA 1/6W
	620 006 1957	Potentiometer 20KB (Linear Motor Offset)	1	D128	407 005 8602	DIODE ERA15-02	1	C175	403 011 3501	CERAMIC	120P J 50V	R144	401 025 8208	CARBON	22K JA 1/6W
	620 026 8752	RF Low Pass Filter	1	D129	407 005 8602	DIODE ERA15-02	1	C176	403 010 5704	CERAMIC	12P J 50V	R145	401 024 7707	CARBON	100K JA 1/6W
	620 026 8745	RF Filter	1	D130	407 005 8602	DIODE ERA15-02	1	C177	403 010 5704	CERAMIC	12P J 50V	R146	401 026 1604	CARBON	270K JA 1/6W
	620 028 8699	OSC Coil	1	D131	407 005 8602	DIODE ERA15-02	1	C178	403 010 5704	CERAMIC	12P J 50V	R147	401 025 0004	CARBON	120K JA 1/6W
	620 028 8774	OSC Coil	1	D132	407 005 8602	DIODE ERA15-02	1	C180	403 051 2106	ELECT	4.7U M 50V	R148	401 012 8105	CARBON	100K JA 1/4W
	620 197 1897	Trans,Pulse	1	D133	407 008 0405	DIODE GMB01-BT	1	C181	403 050 1308	ELECT	2.2U M 50V	R149	401 025 1902	CARBON	15K JA 1/6W
	620 021 6821	Pin 1P	1	C101	403 004 0500	CERAMIC	0.047U K 25V	C182	403 074 2701	CERAMIC	0.047U Z 50V	R150	401 027 2600	CARBON	5.6K JA 1/6W
	620 021 6821	Pin 1P	1	C102	403 038 2402	ELECT	100U M 6.3V	C183	403 074 2701	CERAMIC	0.047U Z 50V	R151	401 025 8208	CARBON	22K JA 1/6W
	620 021 6821	Pin 1P	1	C103	403 038 2402	ELECT	100U M 6.3V	C184	403 074 2701	CERAMIC	0.047U Z 50V	R152	401 025 8208	CARBON	22K JA 1/6W
	620 021 6821	Pin 1P	1	C104	403 038 2402	ELECT	100U M 6.3V	C185	403 051 5107	ELECT	470U M 50V	R153	401 024 9305	CARBON	1.2K JA 1/6W
	620 021 5589	Plug 5P	1	C105	403 014 8202	CERAMIC	18P K 50V	C186	403 051 5107	ELECT	470U M 50V	R154	401 027 0309	CARBON	47K JA 1/6W
	620 021 5589	Plug 5P	1	C106	403 014 8202	CERAMIC	18P K 50V	C187	403 050 3708	ELECT	22U M 50V	R155	401 026 1604	CARBON	270K JA 1/6W
	620 021 3950	Plug 6P	1	C107	403 057 0106	POLYESTER	0.01U J 50V	C188	403 177 4503	ELECT	4700U M 25V	R156	401 025 5405	CARBON	2.2 JA 1/6W
	620 021 3998	Plug 10P	1	C108	403 060 5808	POLYESTER	3300P J 50V	C189	403 177 4503	ELECT	4700U M 25V	R157	401 025 5405	CARBON	2.2 JA 1/6W
	620 021 5572	Plug 9P	1	C109	403 067 6204	MT-COMPO	0.15U J 50V	C190	403 047 6309	ELECT	470U M 25V	R158	401 025 7805	CARBON	2.2K JA 1/6W
	620 196 8866	Resonator,Ceramic,4.32MHz	1	C110	403 067 6709	MT-COMPO	0.22U J 50V	C191	403 038 2402	ELECT	100U M 6.3V	R159	401 025 7805	CARBON	2.2K JA 1/6W
	620 197 1910	Resonator,Xtal,16.9344MHz	1	C111	403 067 7300	MT-COMPO	0.33U J 50V	C192	403 038 2402	ELECT	100U M 6.3V	R160	401 026 1307	CARBON	27K JA 1/6W
	409 124 6507	IC LA9200NM	1	C112	403 018 8509	CERAMIC	220P K 50V	C193	403 039 7901	ELECT	100U M 10V	R161	401 026 4902	CARBON	330K JA 1/6W
	409 168 1308	IC LC7860J	1	C113	403 026 9406	CERAMIC	5P C 50V	C194	403 045 0606	ELECT	100U M 25V	R162	401 025 5405	CARBON	2.2 JA 1/6W
	409 123 7109	IC LC3517BS-15	1	C114	403 031 0308	CERAMIC	68P K 50V	C195	403 038 2402	ELECT	100U M 6.3V	R163	401 025 5405	CARBON	2.2 JA 1/6W
	409 164 3801	IC LC6538D-3843	1	C115	403 015 0407	CERAMIC	180P K 50V	C196	403 039 7901	ELECT	100U M 10V	R164	401 026 7002	CARBON	3.9K JA 1/6W
	409 018 5500	IC LA6510	1	C116	403 048 7701	ELECT	0.47U M 50V	C198	403 039 7901	ELECT	100U M 10V	R165	401 026 9600	CARBON	470 JA 1/6W
	409 018 5500	IC LA6510	1	C117	403 031 0306	CERAMIC	68P K 50V	C199	403 039 7901	ELECT	100U M 10V	R166	401 018 4806	CARBON	22K JA 1/4W
	409 174 9602	IC RC4558D	1	C118	403 067 7409	MT-COMPO	0.039U J 50V	C200	403 018 8509	CERAMIC	220P K 50V	R167	401 027 0309	CARBON	47K JA 1/6W
	409 174 9602	IC RC4558D	1	C119	403 018 8509	CERAMIC	220P K 50V	C201	403 018 8509	CERAMIC	220P K 50V	R168	401 024 7400	CARBON	10K JA 1/6W
	409 174 9602	IC RC4558D	1	C120	403 087 2507	STYRENE	1000P J 50V	C202	403 018 8509	CERAMIC	220P K 50V	R169	401 027 5502	CARBON	

P.C.BOARD PARTS LIST (Continued)

P.C.BOARD PARTS LIST (Continued)

I.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty	Ref. No.	Part No.	Description	Q'ty			
35	401 024 7707	CARBON	100K JA 1/6W	1	D901	407 005 3805	DIODE DS442-BT	1	Q309	405 034 6705	TR DTA114-EF	1	R310	401 148 7607	MT-FILM	10K GC 1/4W	1	
36	401 024 7707	CARBON	100K JA 1/6W	1	D902	407 005 3805	DIODE DS442-BT	1	D301	407 005 8602	DIODE ERA15-02	1	R311	402 015 3005	FUSIBLE RES	10 J- 1/4W	1	
37	401 027 3201	CARBON	560K JA 1/6W	1	D903	407 005 3805	DIODE DS442-BT	1	D302	407 005 8602	DIODE ERA15-02	1	R312	402 015 3005	FUSIBLE RES	10 J- 1/4W	1	
38	401 027 3201	CARBON	560K JA 1/6W	1	D904	407 005 3805	DIODE DS442-BT	1	D303	407 050 7308	ZENER DIODE GZA8.2Y-BT	1	R313	401 024 8001	CARBON	1M JA 1/6W	1	
39	401 025 8703	CARBON	220K JA 1/6W	1	D905	407 005 3805	DIODE DS442-BT	1	D304	407 003 5306	DIODE DBA10B	1	R314	401 024 6700	CARBON	100 JA 1/6W	1	
40	401 025 4903	CARBON	180K JA 1/6W	1	D906	407 005 3805	DIODE DS442-BT	1	D305	407 049 6305	ZENER DIODE GZA12Y-BT	1	R315	401 024 6700	CARBON	100 JA 1/6W	1	
41	401 027 0309	CARBON	47K JA 1/6W	1	D907	407 005 3805	DIODE DS442-BT	1	D306	407 049 6305	ZENER DIODE GZA12Y-BT	1	R316	401 024 6700	CARBON	100 JA 1/6W	1	
42	401 026 9907	CARBON	4.7K JA 1/6W	1	D908	407 005 3805	DIODE DS442-BT	1	D307	407 008 0405	DIODE GMB01-BT	1	R317	401 028 0308	CARBON	91K JA 1/6W	1	
43	401 012 7009	CARBON	10K JA 1/4W	1	R901	401 016 4806	CARBON	22K JA 1/4W	1	D308	407 008 0405	DIODE GMB01-BT	1	R318	401 086 5802	MT-FILM	2.7K FA 1/6W	1
44	401 024 7400	CARBON	10K JA 1/6W	1	R902	401 016 4806	CARBON	22K JA 1/4W	1	D309	407 050 5502	ZENER DIODE GZA5.6Y-BT	1	R319	401 026 5503	CARBON	360 JA 1/6W	1
45	401 024 7400	CARBON	10K JA 1/6W	1	R903	401 016 4806	CARBON	22K JA 1/4W	1	C301	403 177 1304	ELECT	1U M 50V	R320	401 024 9305	CARBON	1.2K JA 1/6W	1
46	401 024 7400	CARBON	10K JA 1/6W	1	R904	401 016 4806	CARBON	22K JA 1/4W	1	C302	403 066 2504	MT-POLYEST	0.1U M 250V	R321	401 028 0308	CARBON	91K JA 1/6W	1
47	401 024 7400	CARBON	10K JA 1/6W	1	R905	401 016 4806	CARBON	22K JA 1/4W	1	C303	620 197 2122	Capacitor,3300U,25V,GS	1	R322	401 151 0800	MT-FILM	1.6K FA 1/6W	1
48	401 024 7400	CARBON	10K JA 1/6W	1	R906	401 016 4806	CARBON	22K JA 1/4W	1	C304	620 197 2122	Capacitor,3300U,25V,GS	1	R323	401 052 9803	MT-FILM	180 FA 1/6W	1
49	401 025 7409	CARBON	220 JA 1/6W	1	R907	401 016 4806	CARBON	22K JA 1/4W	1	C305	403 177 4800	ELECT	33U M 16V	R324	401 026 8504	CARBON	430 JA 1/6W	1
50	401 027 3201	CARBON	560K JA 1/6W	1	R908	401 016 4806	CARBON	22K JA 1/4W	1	C306	403 177 4800	ELECT	33U M 16V	R325	401 028 0308	CARBON	91K JA 1/6W	1
51	401 025 8703	CARBON	220K JA 1/6W	1	R909	401 016 4806	CARBON	22K JA 1/4W	1	C307	403 177 4909	ELECT	330U M 16V	R326	401 151 0800	MT-FILM	1.6K FA 1/6W	1
52	401 027 2303	CARBON	560 JA 1/6W	1	R910	401 016 4806	CARBON	22K JA 1/4W	1	C308	403 177 4909	ELECT	330U M 16V	R327	401 052 9803	MT-FILM	180 FA 1/6W	1
53	401 025 8208	CARBON	22K JA 1/6W	1	R911	401 016 4806	CARBON	22K JA 1/4W	1	C309	403 177 4800	ELECT	33U M 16V	R328	401 053 3008	MT-FILM	470 FA 1/6W	1
54	401 026 7408	CARBON	39K JA 1/6W	1	R912	401 016 4806	CARBON	22K JA 1/4W	1	C310	403 001 1906	CERAMIC	0.01U M 16V	R329	401 028 0308	CARBON	91K JA 1/6W	1
55	401 025 8208	CARBON	22K JA 1/6W	1	ASSY,PCB,LED				C311	403 177 4701	ELECT	100U M 16V	R330	401 151 0800	MT-FILM	1.6K FA 1/6W	1	
56	401 027 0309	CARBON	47K JA 1/6W	1	52	620 197 2023	Assy,PCB,LED	1	C312	403 044 0300	ELECT	47U M 16V	R331	401 052 9803	MT-FILM	180 FA 1/6W	1	
57	401 027 8602	CARBON	8.2K JA 1/6W	1	DL801	407 062 7204	LED SEL2213C	1	C313	403 013 7705	CERAMIC	16P J 50V	R332	401 053 3008	MT-FILM	470 FA 1/6W	1	
58	401 026 9602	CARBON	4.7K JA 1/6W	1	DL802	407 062 7204	LED SEL2213C	1	C314	403 013 7705	CERAMIC	16P J 50V	R333	401 148 9106	MT-FILM	1K GC 1/4W	1	
59	401 026 9602	CARBON	4.7K JA 1/6W	1	DL803	407 062 7204	LED SEL2213C	1	C315	403 177 1007	ELECT	100U M 6.3V	R334	401 148 9106	MT-FILM	1K GC 1/4W	1	
60	401 025 0004	CARBON	120K JA 1/6W	1	DL804	407 062 7204	LED SEL2213C	1	C316	403 177 4800	ELECT	33U M 16V	R335	401 018 5801	CARBON	330K JA 1/4W	1	
61	401 025 0004	CARBON	120K JA 1/6W	1	DL804	407 062 7204	LED SEL2213C	1	C317	403 024 1501	CERAMIC	39P J 50V	R336	401 018 5801	CARBON	330K JA 1/4W	1	
62	401 027 5502	CARBON	6.8K JA 1/6W	1	R801	401 021 0701	CARBON	56 JA 1/4W	C318	403 024 1501	CERAMIC	39P J 50V	R337	401 148 7904	MT-FILM	3K GC 1/4W	1	
63	401 024 7400	CARBON	10K JA 1/6W	1	R802	401 021 0701	CARBON	56 JA 1/4W	C319	403 024 1501	CERAMIC	39P J 50V	R338	401 148 7904	MT-FILM	3K GC 1/4W	1	
64	401 024 7400	CARBON	10K JA 1/6W	1	ASSY,PCB,FILTER				C320	403 024 1501	CERAMIC	39P J 50V	R339	401 148 8208	MT-FILM	620 GC 1/4W	1	
65	401 024 7400	CARBON	10K JA 1/6W	1	53	620 202 0136	Assy,PCB,Filter	1	C321	403 177 1403	ELECT	3.3U M 50V	R340	401 148 8208	MT-FILM	620 GC 1/4W	1	
66	401 024 7400	CARBON	10K JA 1/6W	1		620 022 2587	EC Terminal 1P	2	C322	403 177 1403	ELECT	3.3U M 50V	R341	401 148 8208	MT-FILM	620 GC 1/4W	1	
67	401 024 7400	CARBON	10K JA 1/6W	1		620 196 8873	Filter,LC,AC,Line	1	C323	403 177 1403	ELECT	3.3U M 50V	R342	401 148 8208	MT-FILM	620 GC 1/4W	1	
68	401 024 7400	CARBON	10K JA 1/6W	1		620 031 4763	Wire Wrap Terminal	3	C324	403 177 1403	ELECT	3.3U M 50V	R343	401 148 7706	MT-FILM	1.2K GC 1/4W	1	
69	401 024 7400	CARBON	10K JA 1/6W	1	ASSY,PCB,AUDIO				C325	403 067 5603	MT-COMPO	0.1U J 50V	R344	401 148 7706	MT-FILM	1.2K GC 1/4W	1	
70	401 024 7400	CARBON	10K JA 1/6W	1	54	620 197 2276	Assy,PCB,Audio	1	C326	403 067 5603	MT-COMPO	0.1U J 50V	R345	401 148 8109	MT-FILM	510 GC 1/4W	1	
71	401 021 0701	CARBON	56 JA 1/4W	1		411 002 9104	SCR PAN 3X8	2	C327	403 177 1403	ELECT	3.3U M 50V	R346	401 148 8109	MT-FILM	510 GC 1/4W	1	
72	401 021 0701	CARBON	56 JA 1/4W	1		620 196 3366	Heat Sink	1	C328	403 177 1403	ELECT	3.3U M 50V	R347	401 012 9300	CARBON	1M JA 1/4W	1	
73	401 025 8208	CARBON	22K JA 1/6W	1	CN12	620 021 6579	Plug 6P	1	C329	403 177 4701	ELECT	100U M 16V	R348	401 028 0308	CARBON	1M JA 1/4W	1	
74	401 016 4806	CARBON	22K JA 1/4W	1	CN13	620 021 6555	Plug 4P	1	C330	403 177 4701	ELECT	100U M 16V	R349	401 148 8000	MT-FILM	47K GC 1/4W	1	
75	401 012 7009	CARBON	10K JA 1/4W	1	CN14	620 021 6562	Plug 5P	1	C331	403 177 1403	ELECT	3.3U M 50V	R350	401 148 8000	MT-FILM	47K GC 1/4W	1	
76	401 020 2003	CARBON	4.7K JA 1/4W	1	CN15	620 021 1970	Plug 2P	1	C332	403 177 1403	ELECT	3.3U M 50V	R351	401 148 7508	MT-FILM	100 GC 1/4W	1	
77	401 025 3807	CARBON	180 JA 1/6W	1	CN16	620 021 5923	Plug 3P	1	C333	403 177 1403	ELECT	3.3U M 50V	R352	401 148 7508	MT-FILM	100 GC 1/4W	1	
78	401 026 9303	CARBON	47 JA 1/6W	1	IP301	620 017 0734	Protector ICP-5	1	C334	403 177 1403	ELECT	3.3U M 50V						
79	401 027 6608	CARBON	75 JA 1/6W	1	IP302	620 017 0734	Protector ICP-5	1	C335	403 177 1403	ELECT	3.3U M 50V						
80	401 027 5502	CARBON	6.8K JA 1/6W	1	LY301	620 196 1744	Relay,U T-Cross DC24V	1	C336	403 177 1403	ELECT	3.3U M 50V						
81	401 025 7805	CARBON	2.2K JA 1/6W	1	LY302	620 196 1744	Relay,U T-Cross DC24V	1	C337	403 177 1403	ELECT	3.3U M 50V						
82	401 024 8001	CARBON	1M JA 1/6W	1	L301	620 197 9534	Inductor 100UH K	1	C338	403 093 5806	OS-SOLID	6.8U M 6.3V						
83	402 015 4705	FUSIBLE RES	47 J- 1/4W	1	L302	620 197 9534	Inductor 100UH K	1	C339	403 177 5401	POLYPRO	470P J 50V						
84	401 024 7707	CARBON	100K JA 1/6W	1	SC301	620 197 2467	Delay Line,SC-1500Y	1	C340	403 177 5401	POLYPRO	470P J 50V						
85	401 027 0309	CARBON	47K JA 1/6W	1	VR301	620 006 2343	Potentiometer 100KB	1	C341	403 177 5203	POLYPRO	2000P J 50V						
86	401 026 4902	CARBON	330K JA 1/6W	1	VR302	620 006 2343	Potentiometer 100KB	1	C342	403 177 5203	POLYPRO	2000P J 50V						
87	402 016 5404	FUSIBLE RES	4.7 J- 1/2W	1	XT301	620 197 2160	Resonator,19.7568MHz	1	C343	403 177 5609	POLYPRO	820P J 50V						
88	402 016 5404	FUSIBLE RES	4.7 J- 1/2W	1	IC301	409 070 4404	IC NJM2043DD	1	C344	403 177 5609	POLYPRO	820P J 50V						
89	402 034 4700	FUSIBLE RES	0.47 J- 1/2W	1	IC302	409 169 7804	IC NJM78M05FA	1	C345	403 177 5302	POLYPRO	0.027U J 50V						
90	402 034 4700	FUSIBLE RES	0.47 J- 1/2W	1	IC303	409 108 6004	IC NJM431L	1	C346	403 177 5302	POLYPRO	0.027U J 50V						
91	402 015 3104	FUSIBLE RES	100 J- 1/4W	1	IC304	409 180 3007	IC YM3434	1	C347	403 177 5708	NP-ELECT	22U M 16V						
92	401 024 6700	CARBON	100 JA 1/6W	1	IC305	409 183 7903	IC MC74HC14AN	1	C350	403 177 5708	NP-ELECT	22U M 16V						
93	401 024 6700	CARBON	100 JA 1/6W	1	IC306	409 052 1407	IC TC74HC04P	1	C351	403 177 4701	ELECT	100U M 16V						
94	401 024 6700	CARBON	100 JA 1/6W	1	IC307	409 052 1407	IC TC74HC04P	1	C352	403 177 4701	ELECT	100U M 16V						
95	401 024 6700	CARBON	100 JA 1/6W	1	IC308	409 171 1500	IC PCM58P	1	C353	403 093 5806	OS-SOLID	6.8U M 6.3V						
96	401 024 6700	CARBON	100 JA 1/6W	1	IC309	409 171 1500	IC PCM58P	1	C354	403 177 1007	ELECT	100U M 6.3V						
97	401 024 6700	CARBON	100 JA 1/6W	1	IC310	409 180 3205	IC NJM4580D	1	C355	403 070 7809	CERAMIC	150P K 50V						
98	401 024 6700	CARBON	100 JA 1/6W															

REFERENCE VOLTAGE (CD Main P.C.Board Section)

TRANSISTOR DC VOLTAGES														
Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E	Ref. No.	DEVICE	B	C	E
Q101	2SB598	4.3V	1.6V	4.9V	Q108	2SC536	4.1V	4.9V	3.6V	Q114	2SC3400	0V	4.8V	0V
Q102	2SD1012	0.6V	0V	0V	Q109	2SC3400	2.7V	0V	0V	Q115	2SC3400	0V	4.9V	0V
Q104	UN411-D	0V	4.8V	4.9V	Q110	2SC3400	0V	2.7V	0V	Q116	2SC3400	4.8V	0.2V	0V
Q105	UN421-D	4.8V	- 24.4V	-24.4V	Q111	2SA1346	4.8V	4.9V	4.9V					
Q106	2SA608	-0.5V	0V	0V	Q112	2SA1346	0V	4.9V	4.9V			D	G	S
Q107	2SC3400	0V	3.6V	0V	Q113	2SC3400	4.9V	0V	0V	Q103	2SK246	-0.3V	-24.4V	0V

IC PIN NUMBERS DC VOLTAGES																					
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC101	LA9200NM	0V	0V	0V	0V	0V	0V	0V	0V	0.4V	0V	0V	0V	0V	4.9V	0.4V	0.4V	4.2V	0.4V	0.4V	2.9V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		0.4V	2.6V	2.2V	2.3V	0V	2.3V	0V	2.4V	2.4V	0V	0.4V	0.4V	0.4V	0V	0.4V	0.4V	0.4V	3.1V	0.4V	4.8V
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
		0V	0V	-5.0V	0.4V	0.4V	0V	0.4V	0V	-	-	-	-	-	-	-	-	-	-	-	

IC PIN NUMBERS DC VOLTAGES																					
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC102	LC7860J	0V	4.4V	0.5V	2.4V	0V	0.5V	0.5V	0.5V	0.5V	0.4V	0.5V	0.4V	0V	0.5V	0.5V	0.5V	0.5V	0V	0.5V	0.5V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		0.5V	0.4V	0V	0V	0V	0V	0.4V	0.4V	0.3V	4.9V	0.5V	5.0V	0.5V	0.4V	0V	0V	0V	4.9V	4.9V	4.9V
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
		4.9V	0.8V	5.0V	0V	4.9V	0V	0V	0V	5.0V	4.9V	4.9V	5.0V	4.9V	4.9V	0.5V	0V	0V	0V	0V	4.9V
		61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
		0V	3.3V	0.3V	0.3V	5.0V	0V	5.0V	1.0V	0V	0V	0V	4.9V	5.0V	0V	4.9V	0V	0V	0V	5.0V	

IC PIN NUMBERS DC VOLTAGES																						
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	
IC103	LC3517BS	2.3V	2.3V	2.3V	2.3V	1.5V	1.5V	1.5V	1.5V	1.3V	1.3V	1.3V	0V	3.5V	3.4V	3.5V	1.6V	3.6V	3.7V	3.8	3.9	4.0
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	
		4.4V	2.3V	2.3V	4.9V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	


		IC PIN NUMBERS DC VOLTAGES																			
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC104	LC6538D	-7.2V	-17.4V	-24.4V	-24.4V	-23.9V	-24.4V	-24.4V	-24.5V	-24.5V	-24.5V	-24.4V	-24.5V	-24.4V	-24.5V	5.0V	1.9V	2.1V	0V	0V	5.0V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		0V	4.3V	0V	3.2V	0V	0V	0V	0V	0.3V	0V	0V	0V	0V	0.3V	5.0V	5.0V	5.0V	5.0V	5.0V	0V
		41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
		0V	0V	0V	5.0V	4.7V	0V	0V	5.0V	0V	4.8V	0.6V	0V	3.4V	-7.0V	-6.8V	10.9V	-6.8V	-6.5V	-1.2V	-3.5V
		61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80
		-3.4V	-27.5V	-1.5V	-3.0V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

IC PIN NUMBERS DC VOLTAGES																					
Ref. No.	DEVICE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
IC105	LA6510	0V	0V	0V	0V	-15.8V	0V	0V	0V	0V	14.8V	-	-	-	-	-	-	-	-	-	-
IC106	LA6510	0V	0V	0V	0V	-15.8V	0V	0V	0V	0V	14.8V	-	-	-	-	-	-	-	-	-	-
IC107	RC4558D	0V	0.6V	1.3V	-7.0V	0V	0V	0V	7.1V	-	-	-	-	-	-	-	-	-	-	-	-
IC108	RC4558D	-1.9V	0.3V	0.3V	-7.0V	0V	0V	0V	7.1V	-	-	-	-	-	-	-	-	-	-	-	-
IC109	RC4558D	5.5V	5.5V	5.5V	-6.3V	2.7V	2.7V	5.5V	11.0V	-	-	-	-	-	-	-	-	-	-	-	-
IC110	YM3613B	4.8V	0V	2.1V	1.0V	0.6V	4.1V	2.0V	1.7V	2.3V	0V	4.0V	0V	4.8V	0V	0V	0V	0V	2.4V	2.2V	1.8V
		21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
		0V	0V	1.2V	4.7V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
IC111	MC74HC08	2.4V	2.4V	2.4V	1.8V	1.8V	2.2V	0V	0V	4.8V	0V	0V	0V	0V	4.8V	-	-	-	-	-	-
IC112	MC74HC74	0V	2.1V	2.0V	4.8V	0V	4.8V	0V	4.8V	0V	4.8V	0V	4.8V	4.8V	4.9V	4.8V	-	-	-	-	-
IC113	MC74HC04	4.8V	0V	2.1V	2.1V	2.1V	2.0V	0V	0V	4.8V	0V	4.8V	0V	4.8V	4.8V	-	-	-	-	-	-
IC114	MC74HC04	4.8V	0V	4.2V	0V	0V	4.9V	0V	4.8V	0V	0.5V	4.4V	4.4V	0.7V	4.9V	-	-	-	-	-	-
IC115	MC7805CT	10.3V	0V	4.9V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
IC116	MC78L05A	5.0V	0V	10.3V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
IC117	NJM78L07A	7.1V	0V	10.2V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
IC118	MC79L05ACP	0V	-11.7V	-5.0V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
IC119	NJM79L07A	0V	-11.7V	-7.0V	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-


[illegible]

- 18 -


**CONTROL P.C.BOARD
(BOTTOM VIEW)**




**FILTER P.C.BOARD
(BOTTOM VIEW)**




**LED P.C.BOARD
(BOTTOM VIEW)**



**HEADPHONE P.C.BOARD
(BOTTOM VIEW)**




WIRING DIAGRAM




SCHEMATIC DIAGRAM (Audio P.C.Board Section)


AUDIO P.C.B.




LC6538D-3843 BLOCK DIAGRAM



YM3613C BLOCK DIAGRAM




YM3434 BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


LA9200NM BLOCK DIAGRAM




LC7860J BLOCK DIAGRAM



NJM4580D BLOCK DIAGRAM




RC4558D BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


LC3517BS-15 BLOCK DIAGRAM




NJM78L07A BLOCK DIAGRAM




NJM431L BLOCK DIAGRAM




NJM4556S BLOCK DIAGRAM




LA6510 BLOCK DIAGRAM



MC74HC74AN BLOCK DIAGRAM




MC74HC08AN BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)


MC74HCU04N BLOCK DIAGRAM




NJM79L07A BLOCK DIAGRAM



MC7805CT BLOCK DIAGRAM




MC78L05ACP BLOCK DIAGRAM




IC BLOCK DIAGRAM (Continued)









MC79L05ACP BLOCK DIAGRAM




NJM78M05FA BLOCK DIAGRAM




IC & TRANSISTOR LEAD IDENTIFICATION

TRANSISTOR	FRONT VIEW	BOTTOM VIEW	TRANSISTOR	FRONT VIEW	BOTTOM VIEW
2SB598 2SC536			DTA114 DTC114		
UN411 UN421			2SB1274 2SD1913		
2SA1346 2SA608 2SC3400 2SC536 2SD1012			2SK246		
TERMINAL NAME					
B → BASE C → COLLECTOR E → EMITTER			S → SOURCE G → GATE D → DRAIN		


**NJM4580D TOP VIEW
RC4558D TOP VIEW**




**MC74HCU04N TOP VIEW
MC74HC08AN TOP VIEW
MC74HC74AN TOP VIEW**




YM3434 TOP VIEW




LC3517BS-15 TOP VIEW



NJM4556S FRONT/SIDE VIEWS




LA6510 FRONT/SIDE VIEWS




IC & TRANSISTOR LEAD IDENTIFICATION (Continued)


LA9200NM TOP/SIDE VIEWS




LC7860J TOP/SIDE VIEWS




YM3613C TOP VIEW




PCM58P TOP VIEW




LC6538D-3843 TOP VIEW



MC78L05ACP TOP/SIDE VIEWS
MC79L05ACP TOP/SIDE VIEWS
NJM431L TOP/SIDE VIEWS
NJM78L07A TOP/SIDE VIEWS
NJM79L07A TOP/SIDE VIEWS



NJM78M05FA TOP/SIDE VIEWS



MC7805CT TOP/SIDE VIEWS

